# ALVA Coffee Machine

| Model | ALV01CM66 | Control Mode | App Control, Touch Control |
|---|---|---|---|
| Product Color | Black/White | Protocol | Wi-Fi, Bluetooth |
| Rated Voltage(V) | 100-120,220-240 | Product Size | 440*270*350 mm |
| Pump(Bar) | 19 | Net Weight | 10.5 kg |
| Water Tank(L) | 1.7 | | |

## Description

Alva coffee machine connect with your smart phone, it have 5 inch touch screen that can check your coffee and flavor with 7 types of drinks with 19 bar and milk foam machine with high quality fine grinding make your coffee powder perfect, with 250 g large capacity bean bin and have upper warm cup area and lamp that make good atmosphere for drinking coffee support by ALVA app

## pairing method

### App Method
There are two pairing methods for pairing with the receiver and the wireless kinetic switch
- Ordinary pairing
- Directional pairing.

### Physical button Mode
1 - Press the button for 3 seconds, the light will enter a slow flashing state (1 flash in 1 second),
2- the receiver enters the status of "waiting for pairing".
3- At this time, press the button of the wireless switch that needs to be paired once, and the light is off, it means that the pairing is completed.
**Note:** - After the pairing is completed, long press button to cycle dimming.
- If keep pressing the button, the brightness of the light will cycle from the darkest to the brightest for two cycles.
- it will stop when the brightness is maximum.
4- Long press for circular dimming, if the time interval between two long presses for dimming is less than 1 second, the dimming direction (brighter or darker) will be reversed

How to install

# unpair method

## Cancel pairing with wireless

### App Method
1- Enter the App page, click "Pairing" -> "Clear Pairing", and select the corresponding channel.
2- After the clearing is completed, the app will prompt "Clearing Successful".

### Physical button Mode
1- Press the button for 12 seconds, the light will flash-still-off, and then release the button, all information for the wireless kinetic switch that matched with this channel will be cleared.

## Clear Network

### App Method
1- Enter the App page, click "Pairing" -> "Clear Pairing", and select the corresponding channel. After the clearing is completed, the app will prompt "Clearing Successful".

### Physical button Mode
1- Press the corresponding button of receiver for 12 seconds, the light will flash-still-off, and then release the button, all information for the wireless kinetic switch that matched with this channel will be cleared.

## Bridging Mode

1- Press the button for 7 seconds, LED1 changes from slow flashing to fast flashing (2 flashes per second), and release the button when it flashes quickly, and the receiver enters the bridging mode.
2- At this time, the light flashes once every 2 seconds. If need to exit the bridging mode, just repeat the above steps

**How to install**