

## ALVA Smart Kettle

Model	ALV01K66	Rated Power	1850-2200 W
Protocol	WI-FI	Material	Glass, Stainless Steel, Plastic
Rated Voltage(V)	220-240 V	Product Size	230*187*235 mm

## Description

Smart Kettle Wi-Fi Tea Maker with penetrate glass supports alva app

## pairing method

### App Method

There are two pairing methods for pairing with the receiver and the wireless kinetic switch

- Ordinary pairing
- Directional pairing.

### Physical button Mode

- 1 - Press the button for 3 seconds, the light will enter a slow flashing state (1 flash in 1 second),
- 2- the receiver enters the status of "waiting for pairing".
- 3- At this time, press the button of the wireless switch that needs to be paired once, and the light is off, it means that the pairing is completed.

**Note:** - After the pairing is completed, long press button to cycle dimming.

- If keep pressing the button, the brightness of the light will cycle from the darkest to the brightest for two cycles.
- it will stop when the brightness is maximum.

- 4- Long press for circular dimming, if the time interval between two long presses for dimming is less than 1 second, the dimming direction (brighter or darker) will be reversed



How to install



## unpair method

### Cancel pairing with wireless

#### App Method

- 1- Enter the App page, click "Pairing" -> "Clear Pairing", and select the corresponding channel.
- 2- After the clearing is completed, the app will prompt "Clearing Successful".

#### Physical button Mode

- 1- Press the button for 12 seconds, the light will flash-still-off, and then release the button, all information for the wireless kinetic switch that matched with this channel will be cleared.

### Clear Network

#### App Method

- 1- Enter the App page, click "Pairing" -> "Clear Pairing", and select the corresponding channel. After the clearing is completed, the app will prompt "Clearing Successful".

#### Physical button Mode

- 1- Press the corresponding button of receiver for 12 seconds, the light will flash-still-off, and then release the button, all information for the wireless kinetic switch that matched with this channel will be cleared.

### Bridging Mode

- 1- Press the button for 7 seconds, LED1 changes from slow flashing to fast flashing (2 flashes per second), and release the button when it flashes quickly, and the receiver enters the bridging mode.

- 2- At this time, the light flashes once every 2 seconds. If need to exit the bridging mode, just repeat the above steps



How to install

