

## ALVA A2 smart door lock

<b>Model</b>	ALV14A268	<b>Material</b>	aluminum alloy
<b>User Capacity</b>	100Pcs	<b>Battery</b>	8PCS* AA Alkaline Battery
<b>Network</b>	bluetooth	<b>SIZE</b>	Front Plate 80mm*396mm*18.8mm Aluminum Alloy back Plate 80mm*396mm*18.8mm Aluminum Alloy

## Description

Alva A2 slim smart lock provide you luxurious look and smart access control, You have multiple entry modes: fingerprint, touch screen (pin code), iccard, mechanical keys and compatible with alva app Also for multiple indoor unlocking methods: unlocking by the short press and locked inside by long press, emergency manual knob for fast response and quick on/off button key to unlock for children and elderly Also have smart doorbell function when guest comes to remind you.



## Product Features

### Unlocking Way

Fingerprint/Pin Code/Mechanical Key/IC Card/alva App

### System Protectio

if you input wrong fingerprint or password more than 5 times in 1mins, the lock would make alarming voice and be frozen 3mins.

### Alert alarm

if the door is wrongly operated, the lock will sound an alarm to alert and keep the home safe

## pairing method

### App Method

1- Enter the App page, click "Pairing" -> "Start Pairing", and select the corresponding channel.  
2- After the App page displays "waiting for pairing", press the corresponding button of the wireless kinetic switch that needs to be paired. It can complete the pairing. (the App will prompt "Pairing succeeded" after the pairing is completed.)

### Physical button Mode

1- Press the button for 3 seconds, the light will enter a slow flashing state (1 flash in 1 second is a slow flash. LED1 indicates L1 output, LED2 indicates L2 output, double-click the button to switch the channel), the receiver enters the status of "waiting for pairing".  
2- At this time, press the button of the wireless switch that needs to be paired once, and the light is off, it means that the pairing is completed.



How to install



## unpair method

### Cancel pairing with wireless

#### App Method

- 1- Enter the App page, click "Pairing" -> "Clear Pairing", and select the corresponding channel.
- 2- After the clearing is completed, the app will prompt "Clearing Successful".

#### Physical button Mode

- 1- Press the button for 12 seconds, the light will flash-still-off, and then release the button, all information for the wireless kinetic switch that matched with this channel will be cleared.

### Clear Network

#### App Method

- 1- Enter the App page, click "Pairing" -> "Clear Pairing", and select the corresponding channel. After the clearing is completed, the app will prompt "Clearing Successful".

#### Physical button Mode

- 1- Press the corresponding button of receiver for 12 seconds, the light will flash-still-off, and then release the button, all information for the wireless kinetic switch that matched with this channel will be cleared.

### Bridging Mode

- 1- Press the button for 7 seconds, LED1 changes from slow flashing to fast flashing (2 flashes per second), and release the button when it flashes quickly, and the receiver enters the bridging mode.

- 2- At this time, the light flashes once every 2 seconds. If need to exit the bridging mode, just repeat the above steps



How to install

